

M100
POWERSMART
BLUETOOTH HEADSET



User's Guide

www.mobileedge.com

1. Introduction

Thank you for your purchase. The *M100 PowerSmart Bluetooth Headset* is an advanced wireless headset for Handsfree operations. The M100 can be connected to any Bluetooth device that supports a Headset or Handsfree profile. Three comfortable earpiece sizes are included for an individualized secure fit.

The *M100 PowerSmart Bluetooth Headset* is convenient to wear and very lightweight. With its easy twist and fold design and modern architecture, you can drive or walk the streets with Handsfree confidence. This instruction manual will get you started!

1.1. Product Features

- Bluetooth V2.0, 1.2, 1.1 compliant
- Supports Headset & Handsfree profiles
- High performance built-in speaker
- Noise suppression and echo cancellation
- Red and blue LED indicators for Bluetooth operations, battery and charging
- Up to 6 hours of talk time and 150 hours of standby time
- Ultra Power Saving Mode up to 60 days
- Smart Connection™ Allows you to answer calls by simply folding the Headset
- Auto key lock prevents accidental calls when in the upright unfolded position
- Three (3) Ear Bud sizes for comfortable individualized fit
- Charge with either of the included AC charger or USB adapter

1.2. Product Specifications


- Weight – less than 10 grams
- Standards – Bluetooth Specification 2.0 compliant
- Range – 10 meters
- Support Profile – HSP, HFP
- Charger – USB Adapter, AC Adapter
- Charge Time – 2 hours
- Dimensions – 60 mm x 19 mm x 14.8 mm

1.3. Package Contents

- M100 PowerSmart Bluetooth Headset
- USB Adapter - AC/DC Charger Adapter
- Ear Buds (3 sizes)
- Lanyard (strap & clip)
- User's Manual

2. Operating Procedures

Buttons



B

MFB
(Multi-Function Button)

2.1. Charging the Battery

- **Before using the headset, charge the battery for at least 2 hours.**
- Charge with either the AC Charger or connect the USB Adapter to your computer.
- While charging, headset LED will turn red. When fully charged, LED will turn blue.

2.2. Switching the Bluetooth Headset ON/OFF

- To power the headset on, click and hold MFB until Headset LED lights up blue and then periodically blinks blue.
- To switch power off, click and hold MFB until Headset LED lights up red and shuts down.

2.3. Handsfree Operations

Function	Action / Tone Indicator
Pairing Mode	Powered OFF, click and hold MFB continuously for about 8 seconds until LED is continuously displayed. From a Bluetooth phone, search for device and establish the connection. If prompted for pin key, enter '0000.' The LED will flash 10 times once connected.
Answer Call	Answer call by folding headset. If headset is already folded, press the MFB on your headset to answer call.
Make Call	Most phones automatically connect to headset once phone number is dialed. If your phone does not support this function, press the MFB for one second to transfer the call.
Redial	Press the MFB for one second. Note: When MFB is pressed, some phones display the last number dialed or received. Press MFB again to redial. Most phones allow direct redialing by clicking MFB just once.
Voice Dial	Make sure your phone supports voice dialing and that it is activated. Ensure voice tags have been recorded. To voice dial, press MFB in idle Handsfree mode. Follow the instructions message from your phone to complete voice dialing.
Volume Control	Click (+) or (-) to adjust volume during Handsfree mode. The tone will increase or decrease sound while being adjusted.
End Call	Press MFB. If the other party ends the call first, the headset automatically returns to Handsfree standby mode.
Reject Call	Press and hold MFB until mobile phone stops ringing.
Ultra Power Save Mode	Setting: Press and hold the MFB and volume (-) button simultaneously until the LED light blinks. Releasing: Press and hold the MFB and volume (+) button simultaneously until the LED light blinks.
Mute	While talking, press the volume (+ or -) button for one second. To reengage or unmute, press the volume (+ or -) button for one second.
Call Waiting/On Hold	To place a call on hold and answer another call, press the MFB for one second and answer the second call. Press the MFB for one second to switch back and forth between calls. Press the MFB for less than a second to end a call.

Adjusting Transmitted Sound Level	<p>Factory settings are set in the middle of five level settings. Adjust volume when headset is folded, press and hold the volume (+) button for eight (8) seconds to increase one level. To increase the volume more repeat the same step. To lower the volume, press and hold the volume (-) button for eight (8) seconds to decrease one level.</p> <ul style="list-style-type: none"> • Default setting – Purple LED blinks two times. • One level up from factory setting – Blue LED blinks one time. • Two levels up – Blue Led blinks two times. • One level down from factory setting – Red LED blinks one time. • Two levels down – Red LED blinks two times.
Setting LED Blinking Mode	<p>LED Blinking on: In type fold, press and hold volume up (+) and volume down (-) button simultaneously until the blue LED blinks. In this mode, blue LED blinks periodically.</p> <p>LED blinking off: In type fold, press and hold volume up (+) and volume down (-) button simultaneously until the red LED blinks. In this mode, red LED blinking stops.</p>

3. Troubleshooting

- *I hear electronic static noises* – For best sound quality always wear the headset on the same side as your mobile phone.
- *I can not hear anything* – In crease the volume of the headset, ensure the headset is paired with the mobile phone.
- *I have problems pairing even though my phone indicates it is connected* – You may have deleted your headset pairing connection on your phone. Follow the pairing instructions in your phone's user manual.
- *Will the M100 work with other Bluetooth devices?* – The Mobile Edge M100 is designed to work with Bluetooth mobile phones. It will work with other Bluetooth devices that are compliant with Bluetooth version 1.1, 1.2 and support a headset/Handsfree profile.

4. General Information

- Avoid storage of extreme temperatures, as this will affect the battery life of the M100.
- Do not expose the M100 to rain or other liquids.

- Keep away from children and animals.
- Please do not disassemble.
- Please only use the certified charger that came within the original packaging.

5. Warranty

Mobile Edge is pleased to provide the original purchaser of this accessory product a warranty for defects in material or workmanship under normal use and service for one year from the date of purchase. If you need to make a warranty claim, please provide the original receipt, on-line registration, or other acceptable documentation. This limited warranty does not cover any damage due to accident, misuse, abuse or negligence. Please contact Mobile Edge Customer Service at info@mobileedge.com or 714-399-1400 for warranty service.